VOLCLAY® WATERPROOFING SYSTEMS	DRAWING DETAIL: VE-A-0040	DRAWN BY: HAYDEN L.	DATE: 15/12/2015
BUTT PRECAST PANEL - VERTICAL JOINT DETAIL (NO ACCESS)	SCALE: NTS	VERIFIED BY: DOUG J.	VERSION: 1.0

1. PLACE PANELS WITH VOLCLAY VOLTEX BONDED TO PANELS
2. BACKFILL: REFER TO ALLCO TECHNICAL BACKFILL DOCUMENTATION
3. PLACE OUTER PEF ROD FROM INSIDE FACE
4. PLACE INTERNAL PEF ROD & DETAIL WITH SEALANT
5. FILL VOID WITH VOLCLAY WATERSTOPPAGE SEAL
6. SEAL TOP WITH PANEL SEALANT

The information and data contained herein are believed to be accurate and reliable. This information does not constitute a warranty and should be used in conjunction with the project specification document and Quality Assurance manual supplied by Allco Waterproofing Solutions Ltd
Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from this information. © Allco Waterproofing Solution Ltd 2011

BRANZ Appraised
Appraisal No. 507 [2006]

For Technical Advice Contact:
Web: www.allco.co.nz
Email: info@allco.co.nz
Telephone: 09 448 1185
Facsimile: 09 448 1186